

**FA**  
Mechanical Force Gauge

**Push / Pull Mechanical Force Gauge with  
Peak-Hold function**

Warranty

**24  
Months**

Included



Included



**Technical Highlight:**

**Accuracy:**  
±1% of Capacity



Delivered in a  
**hard carrying case**

Dimensions:  
L 230 x B 60 x H 50 mm;  
Weight: 560 g

**Standard Attachments:**  
as shown below;  
Extension rod: 90 mm



**Real time or Peak Hold Switch** to observe transients or capture peaks by a drag indicator

**Zeroing** by a short push of the switch

**Tare Ring** for an easy calibration of the tester

**Dual Scale:** Shows NEWTON and kg

Can be **mounted** on all manual **test stands** or the optional handle

<b>Model</b>	<b>Max</b>	<b>Reso- lution</b>	<b>ISO Calibration Certificate</b>
<b>FA 10</b>	— 10 N	— 0,05 N	- CF 500
<b>FA 20</b>	— 20 N	— 0,10 N	- CF 500
<b>FA 30</b>	— 30 N	— 0,20 N	- CF 500
<b>FA 50</b>	— 50 N	— 0,25 N	- CF 500
<b>FA 100</b>	— 100 N	— 0,50 N	- CF 500
<b>FA 200</b>	— 200 N	— 1,00 N	- CF 500
<b>FA 300</b>	— 300 N	— 2,00 N	- CF 500
<b>FA 500</b>	— 500 N	— 2,50 N	- CF 500