

Advent Petrol Engine Tachometer A2105

The **A2105** is ideal for testing most types of single and multicylinder petrol & gas engines with electric and electronic ignition systems, designed for hand-held testing and hands free bench testing of engines, chain saws, disc cutters, horticultural and Forestry machinery, pumps, compressors and similar engine driven equipment.

- Hands free operation mode
- Ideal for engines with overspeed control, 214 stroke
- Single & Multicylinder
- Remote antenna cable with clip
- Antennae probe

Automatic Measurement - Auto switch off

The units operate continuously once powered on, measurement will be automatic while speed pulses are being received from the Transducer, after approximately 5 minutes of inactivity the instrument switches off.

Inverting display

This unique feature allows the Tachometers to be used through 180 degrees rotation, providing easy readability in difficult applications.

Maximum revs capture mode
Allows the user to take "single shot" peak speed checks on machines with automatic overspeed governors and centrifugal clutch checking, the actual maximum speed is held in the display.

General Specification

Speed range	60 to 18,000rpm
Resolution	10 rpm
Accuracy	0.05% +/- 1 digit
Display	5 Digit LCD - Inverting
Update	0.8 sec (normal mode)
Capture Mode	0.1sec
Controls	On, Invert, Capture, Ratio
Auto Off	Auto shutdown if inactive for 5 minutes
Signal Indicator	Yes in display
Low Battery ind.	Yes in display
Power	4 x AAA batteries - supplied
Carrycase	Supplied

A2105 Kit includes-

- 1 pc A2105 Tachometer
- 4 pcs AAA Batteries
- 1 pc Instructions
- 1 pc Calibration certificate
- 1 pc Stub Antenna
- 1 pc Cable antenna
- 1 pc Custom Carry case



Order codes	Description
A2105	Petrol Tachometer Kit